
MICROCONTROLLER TECHNOLOGY

1st Edition – Type V 0150

© **hps SystemTechnik**

Lehr- + Lernmittel GmbH

Altdorfer Strasse 16
88276 Berg / Germany

Phone: + 49 751 / 5 60 75 80
Telefax: + 49 751 / 5 60 75 17
Internet: <http://www.hps-systemtechnik.com>
E-mail: export@hps-systemtechnik.com

Order no.: V 0150

All rights reserved. No part of this publication may be reproduced, transmitted, stored in a retrieval system, nor translated into any human or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise, without the prior permission of hps SystemTechnik.

0.5.1



Contents

Preface	1	2.4.1 Basic principles.....	29
1. Introduction	3	2.4.2 Programming the SFR ADCON and DAPR in direct or program mode	34
1.1 History	3	2.4.3 Exercises	36
1.2 Comparison microcontroller/micro- processor	3	2.5 Timers and their functions	39
1.3 Microcontroller 80C535	4	2.5.1 Basic principles - Timer 0 and 1	39
1.3.1 Structure	4	2.5.2 Basic principles - Timer 2.....	44
1.3.2 Memory organization	5	2.5.3 Exercises	48
1.3.3 Accumulator	7	2.6 Interrupt control in BASIC	53
1.3.4 Program Status Word Register (PSW)	7	2.6.1 Basic principles.....	53
1.3.5 B Register.....	8	2.6.2 Exercises	54
1.3.6 Stack Pointer (SP)	8	2.7 Serial interface of the 80C535	57
1.3.7 Data Pointer (DPTR)	8	2.7.1 Basic principles.....	57
1.3.8 Interrupt systems	9	2.7.2 Exercises	58
1.3.9 Technology.....	9	2.8 Monitoring equipments of the 80C535 ..	59
1.3.10 Reset function	9	2.8.1 Basic principles.....	59
1.4 Communication between PC and MICROCONTROLLER BOARD	11	2.8.2 Exercises	60
2. Programming the microcontroller 80C535 in BASIC	13	2.9 EEPROM programming in BASIC	61
2.1 Operating instructions in BASIC	13	2.9.1 General	61
2.1.1 Direct mode	13	2.9.2 Programming of the EEPROM.....	61
2.1.2 Program mode	13	2.9.3 Exercises	62
2.1.3 Storing of BASIC programs	15	3. Experiments with external hps systems	63
2.1.4 Loading BASIC programs	16	3.1 Stepping motor control with the STEPPING BOARD (Type 5132)	63
2.2 Programming of I/O ports in BASIC	17	3.1.1 General	63
2.2.1 Basic principles	17	3.1.2 BASIC program.....	64
2.2.2 Exercises	19	3.2 Battery charger with the ELECTRONIC BOARD (Type 1018)	67
2.3 Analog output through DA converter ..	25	3.2.1 General	67
2.3.1 Basic principles	25	3.2.2 Specifications	68
2.3.2 Exercises	27	3.2.3 Layout phase	70
2.4 Analog input through AD converter	29	3.2.4 BASIC program.....	71

4.	Programming the microcontroller 80C535 in Assembler	73
4.1	Assembler operating instructions	73
4.1.1	General	73
4.1.2	Input in direct mode	75
4.1.3	Programming in Assembler	76
4.1.4	Disassembling of Assembler programs	77
4.1.5	Storing Assembler programs	77
4.1.6	Loading Assembler programs	78
4.1.7	Testing Assembler programs	79
4.2	Programming of I/O ports in Assembler	81
4.2.1	Basic principles	81
4.2.2	Exercises	83
4.3	Analog output through DA converter	87
4.3.1	Basic principles	87
4.3.2	Exercises	89
4.4	Analog input through AD converter	93
4.4.1	Basic principles	93
4.4.2	Programming the SFR ADCON and DAPR	98
4.4.3	Exercises	100
4.5	Timers and their functions	103
4.5.1	Basic principles - Timer 0 and 1	103
4.5.2	Basic principles - Timer 2	108
4.5.3	Exercises	112
4.6	Interrupt control in Assembler	117
4.6.1	Basic principles	117
4.6.2	Enabling interrupts	120
4.6.3	Additional interrupt functions	122
4.6.4	Interrupt priorities	125
4.6.5	Exercises	126
4.7	Serial interface of the 80C535	129
4.7.1	Basic principles	129
4.7.2	Baud rates	131
4.7.3	Exercises	133

4.8	Monitoring equipments of the 80C535	137
4.8.1	Basic principles	137
4.8.2	Exercises	138

5.	Interconnection between BASIC and Assembler	139
5.1	General	139
5.2	Exercises	140

Solutions - BASIC	S 1
--------------------------	-----

Solutions - Assembler	S 7
------------------------------	-----

Solutions - Interconnection between BASIC and Assembler	S 15
--	------

Appendix	A 1
-----------------	-----

1.	Terminal program TERM	A 1
1.1	Summary of instructions	A 1
1.2	Error messages	A 1
2.	Monitor mode	A 2
2.1	Error messages	A 2
3.	BASIC interpreter	A 2
3.1	Summary of instructions	A 3
3.2	Error messages	A 6
4.	Assembler	A 7
4.1	Abbreviations	A 7
4.2	Addressing modes	A 8
4.3	Summary of instructions	A 9
5.	Used Measuring Instruments	A 14

Foils	F 1
MICROCONTROLLER BOARD (Type 3850)	F 1
STEPPING BOARD (Type 5132)	F 2
ELECTRONIC BOARD (Type 1018)	F 3